

ABS

1	GND*	20	LF OUT valve	38	RF IN valve
2	LF IN valve	21	RF OUT valve	39	
3	Solenoid power +12V	22	MC2 valve	40	MC1 valve
4	-	23	-	41	Pedal position sensor
5	-	24	-	42	-
6	-	25	-	43	PCK1
7	-	26	-	44	PCK2
8	P RR	27	RR GND	45	RR sensor
9	P LR	28	LR GND	46	LR sensor
10	P RF	29	RF GND	47	RF sensor
11	P LF	30	LF GND	48	LF sensor
12	P MC1	31	Sensor GND	49	Sensor Power
13	P MC2	32	Brake light switch	50	CAN1H
14	P ACC	33	Solenoid Power +12V	51	CAN1L
15	Pump relay	34	Main relay	52	ABS indicator
16	FR1 BP	35	MTT	53	+12V
17	FR1 BM	36	LR IN valve	54	
18	RR OUT valve	37	RR IN valve	55	LR OUT valve
19	GND				